



## Laptops: Pop That Drive (Really Tiny Tip)

**Scenario:** Your laptop has a DVD drive. You finished using it to install some software or copy data, etc. – but then you shut down the laptop without removing the DVD from its drive.

Have many times had you done this – and then thought you had to turn the laptop back on to be able to open the DVD door? Well...you don't have to.

Built-in to every CD/DVD drive is a tiny little "eject" pinhole (see here).

Simply unfurl a (small) paperclip and poke the end into the hole.

You'll feel a small "clunk" – and the DVD door will pop open.

